



## GHOSTWOOD SKINZ PEEL & STICK PLANKS

**STEP 1** - Acclimate product 48-72 hours, leave in band wrap.

**STEP 2** - Clean wall, remove dust and debris.

**STEP 3** - Paint or prime your wall black. **DO NOT APPLY TO BARE DRYWALL.**

**STEP 4** - Make sure baseboard is level. If floors are not level, or there is a bow in the ceiling, measure and mark increments of 5". Mark with a chalk line to ensure you are staying level throughout the wall.

**STEP 5** - Peel and stick product starting at the baseboard in a straight line.

**STEP 6** - Use J-Roller and apply pressure to each board.

**\*WALL OUTLET TIP** - Place Ghostwood Skinz over the outlet, making sure it is parallel and touching the previous piece. Mark the outsides of the outlet as well as the bottom. Find the width of the outlet and mark your cut. Place two shims behind the frame of the outlet to level with the Ghostwood Skinz wall.

**WARNING** - Interior use only. Could damage drywall.

